


Bedienungsanleitung / Operating Instructions

iFIT

Abpressstopfen

Pressure Plug




Bedienungsanleitung / Operating Instructions






iFIT Abpresstopfen / Pressure Plug

Der Abpresstopfen wird zur Prüfung auf Dichtigkeit von Rohrleitungssystemen vor der Inbetriebnahme bzw. Fertigmontage verwendet. Eine eigenmächtige Veränderung oder eine nicht bestimmungsgemäße Verwendung des Abpresstopfens schliesst eine Haftung des Herstellers für daraus resultierende Schäden aus.

The pressure plug is used to check piping systems for leaks before commissioning or final assembly. Unauthorized modification or improper use of the bead breaker plug precludes any liability on the part of the manufacturer for any resulting damage.



- 1 Sechskant / Hexagon
- 2 Aussenhülse / Outer sleeve
- 3 Dorn / Mandrel
- 4 O-Ring / O-ring
- 5 Rohr / Tube



Local support around the world

Visit our webpage to get in touch with your local specialist:

www.gfps.com/our-locations



The information and technical data (altogether "Data") herein are not binding, unless explicitly confirmed in writing.
The Data neither constitutes any expressed, implied or warranted characteristics, nor guaranteed properties or a guaranteed durability. All Data is subject to modification. The General Terms and Conditions of Sale of Georg Fischer Piping Systems apply.



gfps-350946006-manual-ifit-abpresstopfen
e / 10.22 /

© Georg Fischer JRG AG

Hauptstrasse 130

CH-4450 Sissach/Switzerland

Telefon +41 (0) 61 975 22 22

info.jrg.ps@georgfischer.com

Printed in Switzerland